KaiVac®1200 Series Operator and Parts Manual

KaiVac 1215 Kaivac Manual Serial#137 on





Read First

INSTALL DATE

Please fill out card for future recor	ds
Install date Serial No.	
Seliai No	

Read this manual prior to operation. This machine will operate at its optimal efficiency if:

- The machine is operated as described in this manual.
- The machine is maintained properly and regularly-per maintenance instructions.
- The machine is maintained with manufacturer parts only.

Carefully unpack and inspect your new KaiVac cleaning machine for shipping damage. Each unit is tested and thoroughly inspected before shipping. For instructions regarding shipping damage, contact Kaivac, Inc. immediately All returns must have a Return Authorization Number (RAN), which is available by calling Kaivac, Inc. Technical Support Department. Remember to protect your investment by registering your Warranty form on page ii.

TABLE OF CONTENTS

Getting Started Limited Warranty Protection Plan	
Warranty Registration Form	i
Introduction	
Safety Precautions	2-3
•	
Operating your KaiVac	
Out of Box Setup Instructions	
Preparing your KaiVac for use	
Operating your KaiVac using the S-I-M-P-L-E Process	
Maintaining your KaiVac	
Machine Maintenance	<u>-</u>
Vac Tank Cleanout Instructions	
Vac Tank Removal Instructions	
Black Box Removal Instructions	
Troubleshooting	10-12
Machine Diagrams	13-19
Parts Listings	

Limited Warranty Protection Plan

The KaiVac has been engineered and tested to provide long lasting performance. This warranty covers defects in workmanship or materials under normal use and service from the date of purchase.

Kaivac, Inc. warrants the following components to be free from defects in materials and workmanship for these time periods:

- 1.) Extended Warranty for end users who use only Kaivac chemicals for the life of the machine.
 - 5 years on rotationally molded parts
 - 3 years on other parts (excluding wear items)
 - 1 year on labor
- 2.) Standard Warranty (for approved non-Kaivac chemicals)
 - 1 year parts and labor
- 3.) Chemicals that have not been approved by Kaivac. (If uncertain, please call Kaivac to check.)
 - No warranty

All KaiVac replacement parts are guaranteed for 90 days from the date of installation. Normal wear items such as wheels, hoses, seals, gaskets, cords, casters, squeegees and GFCI are excluded from warranty coverage.

All warranty claims must be accompanied by a Return Authorization Number (RAN), which is available by calling the Kaivac, Inc. Customer Service Department. No returns will be accepted without a RAN.

This warranty does not apply to return freight costs, damage or defect caused by accident, negligence, misuse, fire or repair done by anyone other than a Kaivac, Inc. authorized repair center. In no event shall Kaivac, Inc. be liable for incidental or consequential damages, or any damages to persons or property.

Please Note: Under no circumstances will the seller be liable for any loss, damage, expenses or consequential damages arising in connection with the use or inability to use seller's product. Kaivac, Inc. reserves the right to make changes or improvements to its equipment without notice. Some states do not allow the exclusion or limitation of incidental or consequential damages. This warranty is in lieu of any other warranty expressed or implied, including any warranty of merchantability or fitness for a particular purpose.

Warranty Registration Form

To be completed and mailed or faxed by the customer purchasing equipment. Return this warranty card within ten days of purchase.

Purchased By:	
Name	Title
Company	
Street Address	
City	State Zip Code
Phone Number	Fax
Date Purchased/	/ Name of Distributor
•	ated information Yes No
☐ KaiVac® 1715	☐ KaiVac® 1750
☐ KaiVac® 1215	☐ KaiVac® 2150
Serial Number	·
Туј	pe of Business
School/University Hospital/Health Care Contract Cleaner	☐ Industrial ☐ Office ☐ Other
Intended Us	es (check all that apply):
Stripping Stairwen Cleaning Locke	ing Around Machinery Classroom Cleaning Other r and Shower Room ay Cleaning

Thank you for registering for our warranty program. As our way of saying thanks, we'd like to send you a free microfiber KaiTowel.™

Please return completed forms to:

Kaivac, Inc. 401 S. Third Street Hamilton, OH 45011

Or Fax to: (513) 887-4601



IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS

CAUTION

To Reduce the Risk of injury, Read Operating Instructions Carefully Before Using



Risk of injection or injury to Persons - Do Not Direct Discharge Stream at Persons



- Connect to a properly grounded outlet. Do Not Remove Ground Pin
- Inspect Cord Before Using Do Not Use If Cord Is Damaged
- Keep All Conections Dry And Off The Ground
- Do not Touch Plug With Wet Hands
- This Product Is Provided With A Ground Fault Circuit Interrupter Built Into The Power Cord. If Replacement Of The Plug Or Cord Is Needed, Use Only Identical Replacement Parts.
- Test The Ground Fault Circuit Interrupter (GFCI) Before Each Use.
- Do not close a door on the cord or pull the cord around sharp edges or corners.
- Do not run over the cord.
- Keep the cord away from heated surfaces.
- Do not spray liquid from the KaiVac onto electrical outlets or on any electrical devices.
- Turn off the unit before unplugging.
- Do not pull on the cord to unplug. Grasp the plug at the outlet and pull.
- Read Instruction Manual Before Using

Grounding Instructions

THE KAIVAC MUST BE GROUNDED. If it should malfunction or stop working, grounding provides a path of least resistance for the electrical current and reduces the risk of electrical shock. The KaiVac is equipped with a ground fault circuit interrupter (GFCI) to further reduce danger of electric shock. It must be maintained and tested regularly. An equipment grounding cord and plug is included with the unit. The plug must be inserted in an appropriate outlet that has been properly installed and grounded in accordance with all local codes and ordinances. Cutting off the ground wire or using a cord with an ungrounded plug will void the warranty on the unit, and Kaivac, Inc. will NOT accept responsibility for the unit.

Improper connection of the equipment grounding cord can result in the risk of electrical shock. Ask a qualified electrician or service person to check the outlet grounding if you are unsure. Do not modify the plug provided with the KaiVac. If it will not fit the outlet, have a properly grounded outlet installed by a qualified electrician.

IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS



When using this product basic precautions should always be followed, including the following:

- Read all the instructions before using the product.
- To reduce the risk of injury, close supervision is necessary when a product is used near children.
- Know how to stop the product and bleed pressures quickly. Be thoroughly familiar with the controls.
- Stay alert watch what you are doing.
- Do not operate the product when fatigued or under the influence of alcohol or drugs.
- Keep operating area clear of all persons
- Do not overreach or stand on unstable support. Keep good footing and balance at all times.
- Follow the maintenance instructions specified in the manual.

Personal Protection

• it is recomended to wear proper personal protective equipment as required by the chemical product label instructions used in conjunction with the KaiVac.

FOR INDOOR USE ONLY

OPERATION INSTRUCTIONS SAVE THESE INSTRUCTIONS

Inspection

Carefully unpack and inspect your new KaiVac cleaning machine for shipping damage. Each unit is tested and thoroughly inspected before shipping. For instructions regarding any shipping damage, contact Kaivac Inc. immediately. All returns must have a Return Authorization Number (RAN), which is available by calling the Kaivac Inc. Technical Service Department.

Equipment Use

- Use the equipment for the purposes specified by the manufacturer.
- Do not remove the float shutoff.
- Do not run the pump dry. This will void the machine warranty.
- Do not run hot water through the pump. This will void the warranty.
- Always test chemicals for compatibility on surfaces to be cleaned.
- Always be sure the water tank and water line filters are clear of debris.
- Do not use to pick up flammable or combustible materials.
- Replace any damaged cords before use.
- See the S-I-M-P-L-E operation section for proper use of equipment.

Chemical use

- Only use chemicals approved for use with the KaiVac. Use of non-Kaivac chemicals may cause machine damage and will reduce warranty periods.
 Turn chemical line off when not in use.
- Keep the appropriate chemical MSDS on hand at all times.
- Cleaning chemicals should not be put in the water tank (with the exception of KaiDri in small amounts). Chemicals in the water tank can harm operator and machine because:
 - Chemicals in the water tank must pass through the pump, which may cause premature pump failure.
 - Use of chemicals in the water tank voids the warranty.
 - Chemicals in the water tank will be aerosolized and may harm the operator.

Training

- Proper training is required before using the KaiVac. Contact your authorized Kaivac Inc. distributor for training information.
- Instruction placards are attached to each KaiVac and should not be removed.
- These placards show proper cleaning procedures and safety precautions.

Prevention of Water Damage to Buildings

The KaiVac is to be used on water resistant building surfaces only. These include concrete, terrazzo, ceramic tile and quarry tile.


The KaiVac may be used for stripping on vinyl composite tile floors, but daily cleaning of resilient flooring using the KaiVac is not recommended.

Never overflow the water tank or the vacuum recovery tank.

Discontinue use if any leaks occur in the KaiVac.

CAUTION: Prior to cleaning, always inspect area to ensure that the surfaces to be cleaned are water- safe. In addition, check for poor construction, damaged walls and floors, missing or damaged tiles or grout, missing or insufficient caulk, and loose wall coverings. If problems are discovered, resolve them prior to cleaning in order to avoid any harm that may result from exposure to water or cleaning solution.

Out of Box Setup Instructions






After removing machine from container, attach the plastic elbow to the vac tank as shown above.




Attach vac motor hose to barb and vac motor inlet as shown above.



Remove the tools from the vac tank and place them in the appropriate locations as shown above.






Place the brush head onto the telescoping handle located on the left side of machine as shown above.







Make sure all tools are removed from vac tank and replace vac lid on vac tank as shown above. Place tools in tote bag and hang bag over nose of machine.


1200 Series Vac Tank Horn Operation





- (1) Connect the vacuum wand and slinky hose together.
- 2 Rotate the horn assembly so that it is now pointing towards the front of the machine.





- Place hand behind vac hose and slide forward off of horn onto floor.
- Once hose is off and on floor turn on vac motor and proceed extracting.


Preparing your KaiVac for use

1. Fill machine with clean, cool water.	
Prepare the cleaning solution you will be using by attaching the chemical feed line and cap to the top of your chemical bottle and selecting the proper metering tip. (See placards for metering tip information.)	
Check machine for all tools and supplies needed to complete task.	
4. If using a cleaning product that has high foaming use a foam inhibitor to cut down on foam. Pour 2 capfulls of inhibitor in the vac hose with vac running to coat inside of hose.	VAC SWITCH ON BUBBLE BUSTER
5. Check all hoses and spray lines for damage prior to use. If damage is found, do not continue until proper repairs are completed.	
6. Plug in machine and test GFCI (Ground Fault Circuit Interrupter) to ensure it is working properly. You are now ready.	Reset

S.I.M.P.L.E.

No-Touch Cleaning Process

Set-up




nject chemicals




manual brush (optional)




Pressure wash and rinse



oop op



E xtract



Machine Maintenance



Always make sure machine is unplugged before lifting electric cover assembly.

Item


Procedure

Floor Squeegee	 Check condition of rubber squeegee blades and wheels on the floor tool. Rough floor surfaces will cause the blades and wheels to wear out more quickly. Replace as necessary.
Spray Gun	 Check spray pattern. If spray pattern will not pinpoint, clean orifice by removing it with an Allen wrench and flushing. Replace if not pinpointing. If nozzle becomes difficult to move from high to low pressure lubricate nozzle with lithium grease.
Pressure Hose	 Wipe clean after each use. Check for cuts or frays in the hose jacket, particularly at the end of the fittings. Replace hose if cuts are found.
Water Tank	 Check condition of filter in water tank. Clean as needed. Empty the water tank to prevent mildew and bacteria growth. Empty tank by dipping the vacuum hose onto the water tank and transferring the water to the vacuum tank.
Vacuum Tank	 Empty and flush vacuum tank. Clean and disinfect. Check the float shutoff screen to be sure it is not plugged up. A plugged filter screen restricts airflow and results in reduced suction.
Leaks	 Be alert for leaks around hoses, fittings, spray wand, tanks or elsewhere. Discontinue use until leaks are repaired.
Electrical System	 The ground fault circuit interrupter (GFCI) must be tested before each use. Electric cords must be inspected for tears or cuts in the insulation.

Black Box Removal Instructions



Remove all hoses, cords, and tools prior to black box removal.



Laying the machine on its back remove the four yellow wingbolts as shown above.



Placing your foot on one of the two handles, tilt the yellow tanks upward until standing upright.



Locate and disconnect the water line and return line behind the black box on the machine.

Troubleshooting



Always make sure machine is unplugged before lifting electric cover assembly.

Area	Problem	Possible Cause	Solution
Electrical	No power to pump or vac motor.	1. Machine not plugged in. 2. Switch not "on." 3. GFCI tripped. 4. Building circuit overloaded. 5. Switch wires loose. 6. Connections loose.	1. Plug machine in. 2. Check switches for "on." 3. Test and reset GFCI. 4. Check and reset circuit. 5. Disconnect power and check for loose wire. 6. Disconnect power and check for loose wire under panel.
	Electrical burning smell.	Vac motor brushes worn. Vac motor hung up. Pump motor hung up.	Remove vac motor and repair. Release pressure on hose and jog pump switch, or replace.
Vacuum System	No/Weak vacuum.	 Vac tank full. Squeegee blades or wheels worn. Float shutoff screen dirty. Float ball stuck. Damaged hose. Dump hose plug missing. Access lid not tight. Vacuum hose plugged. Too much liquid in vac hose. Vac hose still wrapped. Muffler plugged. Leak in vac tank. 	 Empty vac tank. Replace wheels or blades and check periodically. Wipe off float screen to clean. Tap float and release/clean. Cut and repair/replace. Contact dealer and replace. Tighten lid hand tight. Flush hose to remove debris. Allow air in when vacuuming. Unwrap vac hose fully. Remove HEPA filter and clean. If repairable, clean and dry affected area and seal with silicone.
	Moisture from exhaust.	Vac tank full. Float shutoff missing. Excessive foam in vac tank.	Dump vac tank. Replace. Use defoamer.
Blow Dry	No air flow.	1. Hose disconnected.	1. Reconnect hose.
System	Moisture from nozzle.	1. Water in blow hose.	1. Dry blow line.
	Suction, not blow action.	Vacuum hose connected to vac tank.	Reconnect to vac motor exhaust hose.
DVD System	No power.	Power cord not connected Power switch not on.	Plug cord into DVD player. Turn switch on DVD player on.
(optional)	No picture.	1. Screen is blank.	1. Close and re-open lid. Play.
	No audio.	1. No sound from player	Check volume control knob.

Troubleshooting



Always make sure machine is unplugged before lifting electric cover assembly.

Area	Problem	Possible Cause	Solution
High Pressure System	No water from pump or low pressure.	 Out of water. Gun nozzle plugged. Air in pump (vapor lock). Gun orifice missing. Water tank filter plugged. In-line bowl filter plugged. Bowl filter lid loose. Pressure hose damaged. Quick disconnect leaking. Injector plugged. 11. Pulse hose damaged. 12. Regulator failed. 13. Hose kinked. 14. Seals in pump need replaced.	 Fill water tank. Remove orifice with Allen wrench and clean. Use power prime technique. Replace orifice. Clean tank and filter. Remove filter cover and clean. Gently tighten bowl cover. Repair or replace. Tighten or replace. Remove safety cap from chemical and blow small amounts of compressed air into line. Repair or replace. Replace. Unkink and check for damage Remove and replace seals.
	Bad fan pattern or pinpoint pattern on gun.	Debris in nozzle. Orifice damaged.	Remove orifice with Allen wrench and clean. Remove and replace.
Chemical Injection System	No chemical flow.	 Out of chemical. Safety cap not secure. Chemical valve "off." Safety cap plugged. Spray gun in wrong mode. Metering tip plugged. Injector plugged. Air entering system. Injector installed backwards. 	 Refill chemical. Check safety cap / tighten. Check on / off valve. Replace cap. Make sure gun nozzle is pulled out away from gun chemical mode. Check metering tip for clog. Remove safety cap from chemical and blow small amounts of compressed air into line. Check for air entering system around chemical lines or injector. If fluttering or pulsing sound can be heard while spraying or when machine is running it is possible that your injector is in backwards. Remove and reinstall.

Troubleshooting



Always make sure machine is unplugged before lifting electric cover assembly.


Area	Problem	Possible Cause	Solution
Chemical Injection	Not enough chemical flow.	Metering tip plugged. Wrong metering tip.	Remove and clean. Check and replace per chart.
System Cont'd.	Chemical line blows off safety cap.	1. Debris in injector.	Remove safety cap from chemical and blow small amounts of compressed air into line.
	Water backflows into chemical bottle.	Bad seat on injector check valve. Bad safety cap.	 Check injector o-ring or replace. Replace safety cap.
Dump System	Dump hose will not empty tank.	 Dump hose plug not removed. Clog in bottom of tank. 	Remove plug. Tip dump contents, remove debris.
	Dump hose leaks.	 Hose cut. Clamp loose. Dump plug bushing missing. Plug missing. 	 If leak is less than 4" from tank side, cut and reattach, or replace. Tighten hose clamp. Replace bushing. Replace plug.
Wheels and Casters	Wheels won't roll, or they rub.	 Flat tires. Debris wrapped around axle. Bearings tight. Wheels too loose on axle. Bearings falling out. 	 Inflate tires to 30 p.s.i. Check for debris on axle. Grease bearings. Remove wheel, add washers to take up slack. Replace bearing assembly.
Squeegee	Floor streaks.	1. Worn blades or wheels.	1. Replace wheels and / or blades.
Head	Squeegee head doesn't easily rotate when installed on wand.	Brass ring on wand not in groove. Coupling nut too tight.	Loosen coupling nut and reposition head on groove. Loosen 1/2 turn.
	Head won't stay on wand.	Coupling nut cracked. Brass ring worn.	1. Replace. 2. Replace.
	Premature blade wear.	1. Squeegee wheels worn.	1. Check wheels for wear / replace.
	Sucks to the floor too tightly.	1. Squeegee wheels worn.	1. Check wheels for wear / replace.

Wiring Diagram Kaivac 1215 series

PLUMBING DIAGRAM KAIVAC 1215 SERIES

CHEMICAL JUG 1 BLACK BOX ELECTRICAL COMPARTMENT CHEMICAL ON OFF VALVE CHEMICAL INJECTOR w/ RELIEF BYPASS CHECK VALVE WATER PUMP MINI BALL WATER TANK


WIRING DIAGRAM KAIVAC 1200 SERIES





NOTE: Relief Bypass only used in 1250 units.


Kaivac Tool Arrangement


OPTIONAL TOOLS AND EQUIPMENT SHOWN























PART #	PART DESCRIPTION
	WATER TANK ASSEMBLY
WTY12	WATER TANK YELLOW
CSS204	BRASS PLUG
CSS142	BRASS BARB
MFILT	MUSHROOM FILTER
CSS132	BOLTS FOR CASTERS
CSS133	LOCK WASHERS FOR CASTERS
LCST4	CASTER 4 INCH
LID4	4 INCH LID FOR WATER TANK
CSS17A	SCREWS FOR LID
	VAC TANK ASSEMBLY
VTY135	VACTANK YELLOW
CSS173	1 1/4" NPT x 1 1/2" BARB
VLJH	VACLID/JUG HOLDER
GAS02	GASKET FOR JUG HOLDER
CSS14	BECKSON CLIP TOOL HOLDER
CSS202	SCREWS FOR BECKSON CLIPS
CSS11	SCREWS FOR 9 INCH STRAPS
SUBSS9	9 INCH STRAPS
CSS20	SNAP STUD FOR 9 INCH STRAPS
CSS91	3/8x21/4CAP SCREW
KMB16	3/8 WASHER
CSS03	WORM CLAMP FOR DUMP HOSE
DH26	DUMPHOSE 26 INCH
KMB16	3/8 WASHER
CSS91	3/8×21/4CAP SCREW
CSS11	SCREWS FOR 9 INCH STRAPS
CSS20	SNAP STUD FOR 9 INCH STRAPS
SUBSS7	7 INCH STRAP FOR VAC WAND
SUBSS9	9 INCH STRAPS
CSS14	BECKSON CLIP TOOL HOLDER
CSS202	SCREWS FOR BECKSON CLIPS
KZFLOAT	FLOAT SHUTOFF
HORN	HORN ASSEMBLY
HSPRING	SPRING
KMB16	3/8 SST FLAT WASHER
CSS26	3/8 X 1 1/2 LONG CAPSCREW
CSS151	SNAP STUD

PART#	PART DESCRIPTION
	BLACK BOX ASSEMBLY 1215
VA1215	VALVE ASSEMBLY (SEE PAGE 21)
SPA1215	SWITCH PANEL ASSEMBLY (PAGE 20)
CSS17A	SCREWS TO MOUNT PANEL
CSS07	BOLTS TO MONT VAC TO BOX
CSS156	3/8 x 3/4 YELLOW THUMB SCREW
CSS175	RUBBER GROMMET
CSS07	BOLTS TO MOUNT PUMP TO BOX
CAP12	PLASTIC PLUG
CSS174	SCREW TO MOUNT HOSE CLAMP
CSS130	RUBBER CUSHIONED CLAMP
CSS101	ACORN NUT
CPS12JQC	CHEMICAL INJECTOR W/QD
PA1215	PUMP ASSEMBLY 150PSI (SEE PAGE 17)
CSS72	COTTERPIN
CSS40	1/2 INCH WASHER
CSS01	PUSH CAP NUT
WHL515	5 INCH WHEEL
AX195G	AXLE
BB10	BLACK BOX BODY 1200 SERIES
VMA1200	VAC MOTOR ASSEMBLY (SEE PAGE 18)
PAGE 19	HEPA ASSEMBLY (SEE PAGE 19)
CSS137	LOCKWASHER
CSS03	WORM CLAMP FOR VAC HOSE
CSS141	RUBBER GROMMET FOR ELECTRIC LINE
CPS75	WIRE HARNESS CLAMP
CSS11	SCREW FOR CLAMP
PCKV12	WIRE HARNESS
VMH26	VAC MOTOR INLET HOSE

PART#	PART DESCRIPTION
	1215 DUMD ASSEMBLY (DA 1215 COMBLETE)
	1215 PUMP ASSEMBLY (PA1215 COMPLETE)
CSS08	5/16 U NUT
CSS07	5/16 18x1 HEX HEAD
CPS64	90 DEG BRASS ELBOW
CPS20	HOSE BARB
CSS161	SIZE 6 YELLOW TURN KEY CLAMP
WL1250	INLET HOSE
CPS10	CLAMP
PUMP150	PUMP AND MOTOR ONLY
JWB	JUMPER WIRE BLACK
JWW	JUMPER WIRE WHITE
PHASM	PULSE HOSE ASSEMBLY
	VAC MOTOR
CSS203	1/420 X 1 1/2 HEX HEAD BOLT
CSS44	1/4FLATWASHER
CSS39	1 1/16TO 2 INCH CLAMP
VBRAK	VAC MOTOR BRACKET
CSS27	NYLOC NUT
CSS08	5/16 U-NUT
CSS11	3,/4 INCH SELF DRILLING SCREW
HFH16	HEPA FILTER HOSE 16 INCH
CVM1	3 STAGE 120 VOLT VAC MOTOR
VMH27	VACINLETHOSE

PART#	PART DESCRIPTION
	1200 SERIES HEPA ASSEMBLY
FKEEP1200	FILTER KEEPER
CSS150	1/4" COUPLING NUT
CSS149	1/4 x 3 STUD
HGAS	GASKET
CSS148	1/4" WING FLANGE NUT
BAT1250	BLOW ATTACHMENT COVER
CSS148	1/4 " WING FLANGE NUT
HEPA	HEPA FILTER
CSS146	1/4" PUSH RETAINER
CSS154	1/4 x 3" BOLT
CSS201	SAFETY CAP
	1200 SERIES SWITCH PANEL ASSEMBLY (SPA1215)
CSS17A	3/4" SST SCREW
SWPL1215	PANEL PLATE
RS2	ROCKER SWITCH
	CHEMICAL VALVE ASSEMBLY
CPS50	NYLON BALL VALVE
CSS21	SNAP GRIP CLAMP
CPS01	1/4 INCH BRAIDED HOSE 1,25FT
CPS01	1/4 INCH BRAIDED HOSE 2.18FT